HOMESYSTEM

QUICK USER GUIDE

Aeotec WallMote Quad

Battery-powered Z-Wave Plus wall controller

Manufacturer: **Aeotec** · Model: **Aeotec WallMote Quad (ZW130)**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/aeon-wallmote-quad-nastenny-ovladac/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A wall controller with touch buttons for controlling lights, plugs, locks and scenes through a Z-Wave gateway. It has four touch buttons (multi-tap, 8 functions) and one Action button. Surface mounting only.

KEY FACTS

Model	ZW130
Wireless	Z-Wave Plus (Gen5, 500 series chip)
Range	up to 120 m outdoors
Battery	built-in rechargeable Li-ion 3.7 V, 640 mAh; charging via micro USB 5 V DC (max. 1 A)
Battery life	about 3 months at 10 presses per day
Size / weight	76,8 × 76,8 × 10,9 mm / 71 g
Environment	0 to 40 °C, 8–80 % RH, indoor use only
Mounting	surface mount – magnetic mounting plate with double-sided tape
In the box	WallMote Quad, mounting plate, double-sided tape, micro USB cable

SAFETY INSTRUCTIONS

WARNING

- Indoor use only, in a dry environment. Keep away from open flame, extreme heat and direct sunlight.
- Charge the battery for no more than 3 hours at a time and do not use permanent USB power. Improper use of the battery may damage it.
- The device is not compatible with wall boxes or frames.
- The manufacturer is not liable for damage caused by not following the instructions.

ACTION BUTTON

Press once / twice	inclusion (non-secure / secure S0)
Hold 3 s	wake-up (beep, orange LED, awake 10 min); hold until purple = connectivity test
Hold 12 s	toggles the beep (release at red)
Hold 18 s	toggles the vibration
Hold 20 s	factory reset (release at solid green)

INDICATOR (LED)

Smoothly changing rainbow colours	not paired
🟢 **Green / blue flashing (Action)**	non-secure / secure S0 mode while pairing
🟢 **Solid green / blue**	pairing successful (non-secure / secure)
🔴 **Solid red after pairing**	pairing failed
🔴 **3× red on press**	device is not connected to the hub
🟢 **Orange on / orange off and green**	charging / charged
🟠 **Orange flashing on touch**	low battery

FIRST SETUP

1. On first micro USB connection the buttons calibrate (blue flashing). Then charge the battery (orange LED on; when charged it turns off and green lights).
2. Put the controller (hub) into add-device mode and bring the WallMote close to the hub.
3. Non-secure: press Action once (green flashing). Secure (S0): press Action twice quickly (blue flashing).
4. Success: green / blue lights for 2 s, then orange flashes quickly for up to 10 min (awake state). On failure red lights for 2 s – repeat the procedure.
5. Mounting: clean, grease-free surfaces; stick the double-sided tape to the back of the mounting plate and place the controller at the top left – magnets hold it. Keep the glass at the top to avoid false triggering.

REMOVAL

Put the hub into removal mode, take the controller off the plate, bring it near the hub and press Action. Success = colour gradient for a few seconds, failure = red for 2 s.

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails: https://aeotec.com/products/aeotec-wallmote-quad/
Product: obchod.homesystem.sk/en/aeon-wallmote-quad-nastenny-ovladac/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492