HOMESYSTEM

QUICK USER GUIDE

Fibaro KeyFob

Pocket Z-Wave remote with 6 buttons

Manufacturer: **Fibaro** · Model: **Fibaro KeyFob (FGKF-601)**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/fibaro-keyfob/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A battery-powered remote for devices and scenes in a Z-Wave network. It has 6 buttons, each with click, double and triple click and hold (30 actions), and sequences of 2–5 presses.

KEY FACTS

Model	FGKF-601
Battery	CR2450 3.0 V (included); about 2 years (default settings, max. 5 presses a day)
Wireless	Z-Wave Plus, AES-128; EU 868.4 / 868.42 / 869.8 MHz
Range	up to 50 m outdoors, up to 40 m indoors
Size / weight	70 × 38 × 15 mm
Environment	10 to 40 °C, IP54
Use	13 association groups; Lock Mode (unlock by a sequence of 2–5 clicks, parameter 1)

SAFETY INSTRUCTIONS

WARNING

- A coin cell is dangerous if swallowed: it can cause severe internal burns in as little as 2 hours and death. Keep new and used batteries away from children; if swallowed seek medical help immediately.
- Use only CR2450 3 V batteries with correct polarity. Do not recharge, force discharge, disassemble, heat or incinerate them.
- Always close the battery compartment fully. If it does not close, stop using the device and remove the battery.
- The alarm is a comfort feature, not professional protection. When integrating with an alarm system check further standards.
- Do not use a damaged device and do not repair it yourself. Keep it away from liquids and moisture.
- Do not dispose of used batteries in household waste – take them to a collection point.

ADDING TO THE Z-WAVE NETWORK

1. Put the controller into inclusion mode.
2. Insert the battery.
3. **Press any KeyFob button 3 times**.
4. Wait until the white pulsing ends. A green LED and a message on the controller confirm inclusion.

> **SECURE INCLUSION**
> For secure (Security) inclusion the device must be within 2 m of the controller.

> **REMOVAL AND RESET**
> For the exact removal and reset procedure (combination of designated buttons) see the manufacturer's manual.

REPLACING THE BATTERY

- Open the cover counter-clockwise with the key ring or a coin, replace the battery and close the cover clockwise.

LED MEANING

🔴 **Red flash**	not included / locked
⚪ **Fast white pulsing**	inclusion in progress
🟢 **Green flash**	included / confirmed
🟢 **Red → green**	unlocked
🟢 **Green → red**	locked
3× magenta	low battery
⚪ **2× white**	woken up
🟡 **Yellow flash every 1 s**	transmitting
🔵 **Blue pulse**	entering a sequence
🔴 **3× blue / 3× red**	valid / invalid sequence

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails: https://www.manuals.fibaro.com/wp-content/uploads/2017/01/FGKF-601-EN-T-v0.16_web_22.07.24.pdf
Product: obchod.homesystem.sk/en/fibaro-keyfob/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492