HOMESYSTEM

QUICK USER GUIDE

Heatit Z-Push Button 2

Battery-powered Z-Wave wall controller with two buttons

Manufacturer: **Heatit** · Model: **Heatit Z-Push Button 2 (čierny)**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/heatit-z-push/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A battery-powered Z-Wave wall controller with two rocker buttons (I and O sides). It controls up to 5 associated devices with on/off and dimming and triggers up to 4 scenes via the gateway. Black version (art. 45 126 80).

KEY FACTS

Model	Z-Push Button 2, art. 45 126 80 (čierny), návod ver. 2019-A
Battery	1× CR2450 (lithium coin cell)
Wireless	Z-Wave, EU 868.4 MHz; 500 chip, SDK 6.71.01; S0, S2 Authenticated, S2 Unauthenticated; OTA; sleeping device without routing
Range	up to 20 m (depending on surroundings)
Size / weight	71,2 × 71,2 × 13,6 mm
Environment	IP20; 0–40 °C; 8–80 % RH; indoor use only, keep away from moisture
Mounting	standard European 60 mm wall box; Gira System 55, Elko RS-16 and Schneider Exxact frames; screws or 3M double-sided tape

SAFETY INSTRUCTIONS

WARNING

- A coin cell is dangerous if swallowed: it can cause severe internal burns in as little as 2 hours and death. Keep new and used batteries away from children; if swallowed seek medical help immediately.
- Use only CR2450 3 V batteries with correct polarity. Do not recharge, force discharge, disassemble, heat or incinerate them.
- Always close the battery compartment fully. If it does not close, stop using the device and remove the battery.
- Have the installation done by a licensed electrician according to national regulations.
- Do not use a damaged device and do not repair it yourself. Keep it away from liquids and moisture.
- Do not dispose of used batteries in household waste – take them to a collection point.

BUTTON ON THE DEVICE

Both buttons (group 2) 3 s	inclusion / exclusion; sends the NIF
Both buttons ≥ 10 s	factory reset (LED lights up, then 4 quick blinks)
Single press	keeps the device awake for about 3 s; LED off = not in a network, LED on = in a network
6 quick blinks	inclusion successful
4 quick blinks	exclusion successful / reset done

FUNCTIONS

Group 1 (Lifeline)	up to 5 nodes; reset, battery and scene (Central Scene) reports on every press
Group 2	up to 5 nodes; short press = on/off, hold = dimming
Waking	hold both buttons for about 1 s = awake for about 7 s

FIRST SETUP

1. Check that the device is not in a network: press any button. LED off = free; LED on = remove it from the network first.
2. Put the controller (gateway) into inclusion mode.
3. Hold both group 2 buttons (I and O) for 3 s. The LED lights up; after about 10 s 6 quick blinks = success. The device stays awake for about another 30 s.
4. Removal: put the controller into exclusion mode and hold both buttons for 3 s; after about 7 s 4 blinks = done. Reset (only if the controller is missing): hold both buttons for ≥ 10 s.

> **SECURITY**
> The controller sets the security mode (S0, S2) during inclusion and must support it. Associations are erased when the device is excluded.

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails: https://media.heatit.com/765
Product: obchod.homesystem.sk/en/heatit-z-push/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492