HOMESYSTEM

QUICK USER GUIDE

NOUS C2

Zigbee smart button / switch pusher

Manufacturer: **NOUS** · Model: **C2**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/nous-c2-zigbee-smart-button-and-switch-controller/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A mini-actuator fixed next to a button or switch that physically presses it on a command from the app or a scenario. It makes ordinary devices smart without wiring or replacing switches. It supports short and long presses.

KEY FACTS

Network	Zigbee 3.0, IEEE 802.15.4, 2,402–2,480 GHz
Range	90 m in open area
Mode	click / long press
Max. arm movement	11 mm
Max. pressure	2,0 kgf
Battery	CR2
Operating conditions	−20 … 60 °C, < 99 % RH, IP20
Dimensions	38 × 38 × 38 mm

SAFETY INSTRUCTIONS

WARNING

- Read the manual. Use the device within the temperature and humidity limits given in the manufacturer's data sheet.
- Do not install it near heat sources (e.g. radiators), do not drop it and do not subject it to mechanical stress.
- Do not use chemically active or abrasive cleaners – use a damp cloth.
- Do not disassemble the device yourself – diagnostics and repair must be done only by a certified service centre.

CONNECTING VIA A ZIGBEE GATEWAY

1. Install the **Nous Smart Home** app (Google Play / App Store), grant it all requested permissions and register a new user.
2. The Zigbee gateway must already be added in the app. Connect your smartphone to a **2.4 GHz** Wi-Fi network.
3. Plug the device into the mains. If the indicator does not flash quickly, hold the button for 5–7 seconds – the device returns to factory settings and starts pairing.
4. In the app tap “+” (add device). Auto-scan will offer the new device – confirm pairing. If it does not find it, under “Add manually” choose the category **Smart Switches** and the model **Nous C2**.
5. After pairing rename the device and, if you wish, assign it to a room.

ZIGBEE GATEWAY

A Zigbee gateway is required. You need a Nous E1, Nous E7 or another Tuya-compatible Zigbee gateway. The gateway must already be added in the app and online.

RESET AND REMOVAL

Removing the device from the app (“Delete device” → disconnect and delete all data) returns it to factory settings – pairing must then be repeated. If the Wi-Fi password was entered incorrectly, the app shows “failed to connect to Wi-Fi” after the timer expires, with steps to fix it.

BUTTON TYPES

3 mm – type A	for buttons up to 3 mm
6 mm – type B	for buttons up to 6 mm
6 mm – type C	for rocker (boat) switches up to 6 mm

MOUNTING

Installation: A/B – for buttons, C – for switches.

BUTTON AND BATTERY

- Hold the button for 5 s: the LED blinks and the device enters connect mode.
- Before first use open the cover, remove the insulation sheet and close it. Replace the battery when the app reports a low battery.

NOTE

The manufacturer notes that the internet connection cannot be guaranteed in all cases – it depends on the quality of the communication channel and network equipment, the make and model of the mobile device, the operating system version, etc.

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails.
Product: obchod.homesystem.sk/en/nous-c2-zigbee-smart-button-and-switch-controller/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492