HOMESYSTEM

QUICK USER GUIDE

Shelly i4 Gen3

Wi-Fi controller with 4 inputs for switches and buttons

Manufacturer: **Shelly** · Model: **Shelly i4 Gen3 (S3SN-0024X)**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/shelly-plus-i4/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

An in-wall interface with four inputs that turns presses of ordinary switches and buttons into actions, scenes and webhooks. It has no outputs.

KEY FACTS

Model	S3SN-0024X
Power supply	110–240 V~ 50/60 Hz; <1 W
Inputs and outputs	4 inputs (SW1–SW4), no outputs
Size / weight	37 × 42 × 16 mm / 19 g
Environment	−20 to 40 °C, 30–70 % RH, indoor use only

SAFETY INSTRUCTIONS

WARNING

- Risk of electric shock. Only a qualified electrician may connect the device to the mains.
- Before any change to the wiring switch off the circuit breakers and check with a suitable tester that there is no voltage on the wires.
- There is high voltage on the add-on interface while the device is powered.
- Do not use a damaged device and do not repair it yourself. Keep it away from dirt and moisture.
- Do not let children play with the buttons or switches connected to the device or with the phones and tablets used to control it.

WIRING

Terminal SW1–SW4	input for a switch or button
Terminal L / N	supply 110–240 V~ (live / neutral)

FIRST SETUP

1. Power the device on. On first start it creates its own Wi-Fi network (access point) whose name starts with “Shelly”.
2. Join it with your phone and open **192.168.33.1** in a browser (web interface).
3. In the Wi-Fi settings enter your home network details. You can also use the device in the Shelly Smart Control app (Android, iOS) or at control.shelly.cloud.

> **NOTE**
> After Wi-Fi setup disable the device access point or protect it with a password.

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails: https://kb.shelly.cloud/knowledge-base/shelly-i4-gen3
Product: obchod.homesystem.sk/en/shelly-plus-i4/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492