HOMESYSTEM

QUICK USER GUIDE

Sonoff Basic Gen5

Single-channel 10 A Wi-Fi switch with Matter support

Manufacturer: **Sonoff** · Model: **BASIC-1GS**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/sonoff-basic-gen5-matter-smart-vypinac/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A Wi-Fi switch up to 10 A controlled from the eWeLink app, by voice, schedules and scenes. Supports Matter.

KEY FACTS

Model	BASIC-1GS (Basic Gen5)
Power supply	100–240 V~, 50/60 Hz
Switching current	max. 10 A, resistive load
Wireless	Wi-Fi 802.11 b/g/n 2,4 GHz, Matter over Wi-Fi
Size / weight	80,5 × 41,5 × 23,6 mm / 44,8 g
Environment	−10 to 40 °C, 5–95 % RH non-condensing, indoor use only

SAFETY INSTRUCTIONS

WARNING

- Risk of electric shock. Only a qualified electrician may connect the device to the mains.
- Before any change to the wiring switch off the circuit breakers and check with a suitable tester that there is no voltage on the wires.
- The device and the connected appliance must be protected by a cable protection switch per EN 60898-1, type B or C, max. 10 A, min. 6 kA breaking capacity, energy limiting class 3.
- Do not exceed the stated maximum load. Connect only as shown in the instructions.
- The device is for a single phase only. Check the wiring before fitting the cover, do not switch on without the cover and do not touch live terminals.
- Do not use a damaged device and do not repair it yourself. Keep it away from dirt and moisture.
- Do not let children play with the buttons or switches connected to the device or with the phones and tablets used to control it.

WIRING

Terminal N In	neutral (N) – supply input
Terminal L In	live (L) – supply input
Terminal N Out	neutral (N) – output to the load
Terminal L Out	live (L) – output to the load
Wire	Cu, 16–14 AWG

INSTALLATION

1. Switch off the power (breaker).
2. Remove the cover – insert a metal tool into the notch on the cover.
3. Wire terminals N In, L In, N Out and L Out.
4. Fit the cover and switch the power on.

BUTTON ON THE DEVICE

Short press	on / off
Hold 5 s	pairing mode (10-minute window)

FIRST POWER-ON

After the first power-on the device is in pairing mode. If you do not pair it within 10 minutes, pairing ends – restart it by holding the button for 5 s.

INDICATOR (LED)

2 short + 1 long flash	pairing mode
On	online

1 flash	offline
2 flashes (eWeLink)	router connected, cloud not

FIRST SETUP – EWELINK

1. Install the eWeLink app and scan the QR code on the device.
2. Tap “Add Device” and power the device on. If it is not in pairing mode, hold the button for 5 s (LED: 2 short + 1 long flash).
3. Select your Wi-Fi network and enter the password.

FIRST SETUP – MATTER

1. Scan the Matter QR code in Apple Home, Alexa, Google Home or SmartThings.
2. Pairing: 2 short + 1 long LED flash; on = online, 1 flash = offline.

MAGIC SWITCH MODE (EWELINK ONLY)

- Connect L1 and L2 of the wall switch; the device stays online even with the switch off.
- Sets the power-on state to OFF. Requires a double-pole rocker switch and supports dual control.
- Not compatible with other platforms (Matter).

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails: https://support.sonoff.tech/basic-1gs-usermanual/
Product: obchod.homesystem.sk/en/sonoff-basic-gen5-matter-smart-vypinac/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492