HOMESYSTEM

QUICK USER GUIDE

Sonoff SNZB-02P

Zigbee 3.0 temperature and humidity sensor

Manufacturer: **Sonoff** · Model: **Sonoff SNZB-02P**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/sonoff-zigbee-senzor-teploty-a-vlhkosti-snzb-02p/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A low-power sensor that measures indoor temperature and humidity in real time. It supports a low-battery notification and scenes (scenes and notifications depend on the Zigbee gateway).

KEY FACTS

Model	SNZB-02P
Battery	CR2477, 3 V
Wireless	Zigbee 3.0 (IEEE 802.15.4)
Size / weight	45 × 45 × 17,7 mm / 26,7 g
Environment	−10 to 60 °C, 5–95 % RH non-condensing, altitude < 5000 m, indoor use only

SAFETY INSTRUCTIONS

WARNING

- A coin cell is dangerous if swallowed: it can cause severe internal burns in as little as 2 hours and death. Keep new and used batteries away from children; if swallowed seek medical help immediately.
- Use only CR2477 3 V batteries with correct polarity. Do not recharge, force discharge, disassemble, heat or incinerate them.
- Always close the battery compartment fully. If it does not close, stop using the device and remove the battery.
- Do not use a damaged device and do not repair it yourself. Keep it away from liquids and moisture.
- Do not dispose of used batteries in household waste – take them to a collection point.

BUTTON AND PAIRING

Hold 5 s	pairing mode (180 s)
Short press	check: 1 flash = not added to a gateway, 2 flashes = added

INDICATOR (LED)

Flashing slowly 180 s	pairing mode
On 3 s, then off	pairing successful
Flashes slowly, then off	pairing failed
Flashing slowly 30 s	communication fault

FIRST SETUP

1. Remove the battery insulation sheet to power the sensor on.
2. In the eWeLink app choose Scan and scan the QR code on the device, then “Add Device”.
3. Hold the button for 5 s until the LED flashes slowly.
4. Select your Zigbee gateway and wait for pairing to finish.

> **NOTE**
> After installation press the button: 2 quick flashes mean the sensor is within range of a router or gateway on the same Zigbee network. Compatible gateways: SONOFF ZBBridge, ZBBridge-P, ZBBridge-U, NSPanel Pro, iHost, ZBDongle-P, ZBDongle-E and others listed by the manufacturer.

REPLACING THE BATTERY

1. Press the buckle with a card ejector pin.
2. Turn the bottom cover with a coin or similar tool.
3. Pry the cover open.

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails: https://support.sonoff.tech/snzb-02p-usermanual/
Product: obchod.homesystem.sk/en/sonoff-zigbee-senzor-teploty-a-vlhkosti-snzb-02p/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492