HOMESYSTEM

QUICK START GUIDE

Sonoff CAM-S3W

GlassView – 2K Wi-Fi window camera

Manufacturer: **Sonoff** · Model: **Sonoff CAM-S3W**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/sonoff-cam-s3w-glassview-2k-indoor-wi-fi-window-camera/

This guide belongs to a product purchased at obchod.homesystem.sk. Scan the QR code for up-to-date information, accessories and advice.

The camera sticks to the inside of the glass and watches your yard, driveway or shop window without drilling or outdoor cables. It features anti-glare imaging, colour night vision from ambient light and subscription-free microSD recording.

BASIC INFORMATION

Model	CAM-S3W (CAM GlassView)
Power supply	5 V⎓ 1 A via USB-C (3 m cable included, adapter not included)
Wireless	Wi-Fi 2.4 GHz and 5 GHz (802.11 a/b/g/n)
Image	2K (2304 × 1296), 3 MP, F1.0, 100° field of view
Night vision	colour, from ambient light, no IR illumination
Storage	microSD (TF) up to 128 GB, card not included; no cloud storage
Dimensions / weight	56 × 56 × 38 mm / 61.9 g; white, ABS+PC
Environment	−10 to 40 °C, 5–95 % RH non-condensing, indoor only (behind glass)
Package contents	camera, angled, large flat and small flat bracket, 3 m USB-C cable, 4 cable clips, quick guide

SAFETY INSTRUCTIONS

CAUTION

- Use indoors only; the camera is not designed for outdoor mounting.
- Use a 5 V⎓ min. 1 A adapter. Mounting height max. 2 m.
- Do not disassemble the camera and protect it from water and condensation.

PARTS AND BUTTON

Parts	microphone, speaker, LED indicator, USB-C input, microSD slot, reset button
Button – hold 5 s	pairing mode (beep, lasts 30 minutes)
Button – short press	exit pairing mode

LED INDICATOR

2 short + 1 long (repeating)	pairing mode
Steady on	online
Off	sleep mode
Flashes once, then briefly on	camera left pairing – offline, network error or connection failed
Flashes twice rapidly (2 beeps)	microSD card detected
Flashes once rapidly	someone is watching the live view

WINDOW INSTALLATION

1. Clean both sides of the glass thoroughly where the camera will go.
2. Choose a bracket: large flat (standard, recommended for double glazing), small flat (tight spaces) or angled (tilt up, down or sideways).
3. Place the camera on the bracket and check position and angle in the live view.
4. Remove the camera, peel the film off the bracket adhesive and stick the bracket to the glass.
5. Attach the camera to the bracket (magnetic) and secure the cable with the clips.

FIRST START

1. Download the eWeLink app. Insert a microSD card if you want recording.
2. In the app tap “Scan”, scan the QR code on the guide or camera and select “Add Device”.
3. Connect power. On first use the camera is in pairing mode – the LED flashes 2 short + 1 long.
4. Select your Wi-Fi network, enter the password and wait for “Added completely”.

> **NOTE**
>
> - If the camera is not paired within 10 minutes, pairing mode ends. Hold the button for 5 s until the LED flashes 2 short + 1 long to re-enter it.

SUITABLE GLASS AND PLACEMENT

- Single glazing gives the best image; double glazing may add slight reflections.
- Tinted and Low-E coated glass reduce quality, especially at night. Patterned and frosted glass are not suitable; do not place the camera behind an insect screen.
- At night the camera needs at least some ambient light (street lamp, porch light).

COMPATIBILITY

- eWeLink app: live view, alerts, microSD playback and scenes with Sonoff devices.
- OpenEdge: local web console in a browser without an account; enable RTSP and ONVIF here (Home Assistant, NVR, NAS).
- Amazon Alexa and Google Home: live view on Echo Show and Nest Hub displays. Matter is not supported.

Disposal: A product marked with the crossed-out wheeled bin symbol must not be disposed of with household waste. Take it to a WEEE collection point or return it to the retailer when buying a new device. Dispose of batteries separately at a battery collection point.
Important: this quick guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of discrepancies, the manufacturer's original manual prevails: https://support.sonoff.tech/cams3w-usermanual/
Product: obchod.homesystem.sk/en/sonoff-cam-s3w-glassview-2k-indoor-wi-fi-window-camera/ · Version: 11/2026
Need advice? obchod.homesystem.sk · +421 948 213 492