HOMESYSTEM

QUICK USER GUIDE

NOUS L6Z

Zigbee smart switch 10 A

Manufacturer: **NOUS** · Model: **L6Z**

PRODUCT IN THE HOMESYSTEM E-SHOP

obchod.homesystem.sk/en/nous-l6z-smart-prepinac-10a/

This guide belongs to a product bought at obchod.homesystem.sk. Scan the QR code for current information, accessories and advice.

A Zigbee switch that switches the connected appliance by interrupting the live wire. It must be powered by the N and L wires.

KEY FACTS

Connection	Zigbee (Tuya-compatible gateway required)
Principle	the connected appliance is switched on/off through the live wire
Power	N and L wires

SAFETY INSTRUCTIONS

WARNING

- Read the manual. Use the device within the temperature and humidity limits given in the manufacturer's data sheet.
- Do not install it near heat sources (e.g. radiators), do not drop it and do not subject it to mechanical stress.
- Do not use chemically active or abrasive cleaners – use a damp cloth.
- Do not exceed the stated load – risk of short circuit and electric shock.
- Do not disassemble the device yourself – diagnostics and repair must be done only by a certified service centre.

ADDING TO THE APP

1. Before use: your phone is on Wi-Fi with internet, you know the password, you can access the App Store / Google Play and your router is MAC-open.
2. Install the **Nous Smart Home** app (Google Play / App Store), grant it all requested permissions and register a new user.

3. Power on. In the app open the Zigbee gateway home page (“Zigbee Smart Gateway”; the gateway must already be added) and tap “+” → Add device.
4. Hold the reset button for 5 seconds until the blue LED blinks, then tap “LED already blink” in the app.
5. After a few seconds the device appears – you can rename it. A newly added device needs about 1 minute to connect to the network.

> **ZIGBEE GATEWAY**
> The Zigbee gateway (Nous E1, E7 or another Tuya-compatible one) must already be added in the app and online.

SETTING FAST / SLOW LED FLASHING

- **Fast flashing:** power on, power off after 10 s and on again; hold the reset button for 5 s and check that the indicator flashes rapidly.
- **Slow flashing:** do the same and then hold the reset button for 5 s again until the indicator flashes slowly.

NOTE

The manufacturer notes that the internet connection cannot be guaranteed in all cases – it depends on the quality of the communication channel and network equipment, the make and model of the mobile device, the operating system version, etc.

Disposal: A product marked with the crossed-out wheelie bin symbol must not be put in household waste. Hand it in at an electronic-waste collection point or to the seller when buying a new device. Hand in batteries separately at a battery collection point.
Important: this short guide in English was prepared by HomeSystem s.r.o. for customers of the obchod.homesystem.sk e-shop based on the manufacturer's documentation. In case of differences, the manufacturer's original manual prevails.
Product: obchod.homesystem.sk/en/nous-l6z-smart-prepinac-10a/ · Status: 11/2026
Need help? obchod.homesystem.sk · +421 948 213 492